



MK2 range

doc #


Wall Unit (User Interface)

MK2Q21

Setting temperature offset

5 button unit - Setting temperature offset

Step 1




Shows temp.

then


press in sequence

Step 2




Shows double the actual offset. "2" as shown would cause an offset of +1 deg.

Step 3



Press up or down to increase or decrease the offset.

Step 4




Press off to revert to normal operation and store the changes.

The unit will under- or over-read as per the offset.

If not pressed the unit will revert to the previous settings, none of the changes will be stored and the keys will return to normal operation within a few minutes.

2 button unit - Setting temperature offset


Step 1



Shows temp.


then

Step 2




Shows double the actual offset. "2" as shown would cause an offset of +1 deg.

Step 3



Press up or down to increase or decrease the offset.

Step 4



Press off to revert to normal operation and store the changes.

The unit will under- or over-read as per the offset.

If not pressed the unit will revert to the previous settings, none of the changes will be stored and the keys will return to normal operation within a few minutes.